

Using BF850 RS485 to USB Converter




Figure 1. BF850 USB to RS485 Termination Diagram

Note: RS485 cable used in connecting USB converter to ACU controller is recommended to use Belden 9534 24 AWG 0.6mm, 4 core cable with fail shield