

System Information Page in IBSS2000

Overview

System information page is a configuration page that turn on or off System parameters.

The Button Upload Company Logo is not in used.

The function of various checkbox is described below.

Function	Description
Enable Site Code Page	A tab with 5 field for system site code entry
Enable AFR Central Enrolment	For fingerprint central enrolment on IBSS
Enable [KONE] Lift	For support of KONE Lift on IBSS
Enable 1024 UAG (ACU205/C302)	Add support for 1024 UAG
Enable Display Card Holder Name	For Custom project
Enable 8 Byte Card ID Support	For 8 byte card ID database and controller
Enable 2048 UAG (ACU1000)	Add support for 2048 UAG
Enable 128 Schedule (C302)	Add support for 128 Schedule

When Site Code page is enable the follow tab screen appears

The screenshot shows a Windows-style dialog box titled "System Information Edit". It has a menu bar with "Save", "Download", and "Close" options. Below the menu bar is a tabbed interface with "Action Sequence" and "Site Code" tabs. The "Site Code" tab is active, showing a list of five site codes. Each site code has a text input field, a numeric value, and a range in brackets. The values are: Site Code 1 (empty), Site Code 2 (0), Site Code 3 (0), Site Code 4 (0), and Site Code 5 (0). The range for all is [0..65535].

Site Code	Value	Range
Site Code 1		[0..65535]
Site Code 2	0	[0..65535]
Site Code 3	0	[0..65535]
Site Code 4	0	[0..65535]
Site Code 5	0	[0..65535]