

Terminate ACU1000 Input Board

Overview

ACU1000 input board is an extension board to ACU1000 Main Board, its extend the number of input monitoring zone to 32.

1. DC Input 12V
2. Input Zone 1 to 32




Figure 1. ACU1000 Input Board

1. On board power input DC12V In.
2. There are total 32input zones on the input board for voltage free normally close input device monitoring.